

iPhone

To activate the NFC reader of your iPhone, open Settlings and enter "Control centre" and in "More controls" select the "NFC reader" item with the + button. Then just swipe up (iPhone 78) or swipe down (iPhone X) to open the control centrer and activate the NFC reader. Sky this step if you have an iPhone 11 or newer (on newer devices the NFC reader is always active).

reader is always active).

Once your iPhone's NFC reader is activated, slowly bring it closer to the Product within a short distance (2cm).





ne lower part.

Android

To activate the NFC reader on your Smartphone: go to "Settings" > search for "NFC" in the search bar > make sure that the "NFC" item is active. Otherwise, swipe down to open the control center and activate the "NFC" item."

Bring your Smartphone closer to the Product slowly and within a short distance (2cm).

The NFC sensor is located on the back of the Smartphone. Usually in Android smartphones it is positioned near the camera, in the central part or in



Additional Information:

- The NFC function often must be activated in the smartphone settings in order to be used.
 - To use the NFC function, your smartphone must be unlocked.
- Please note that any smartphone covers may interfere with the NFC connection. If possible, remove the cover from your smartphone before using NFC.
- The recommended distance between your smartphone and the product may vary depending on the smartphone model.

 Regardless of the smartphone model you use, it
- is very important to keep your device secure while transferring data; any movements could interrupt the connection.

 If there are any questions regarding the NFC function on your smartphone, it is always recommended to contact the manufacturer directly.